

Givex Programming Barcodes

Scanning the following barcodes in numerical sequence will program a **Symbol Omnilink LL-500 Scanner** and a **Symbol Dual Track MS-72 Magstripe Reader** for **Givex** card swipe capability.

1.



ANY MAGSTRIPE READER

4.



SKIP AHEAD 1 CHARACTER

2.



SELECT TRACK 2 DATA

5.



SEND UP TO CHARACTER*

3.



SEND ;

6.



<

Scanning Order:

1. Any Magstripe Reader
2. Select Track 2 Data
3. Send ;
4. Skip ahead one character
5. Send up to character*
6. <
7. Send ?
8. Send Control M
9. Save rule
10. Any Magstripe Reader
11. Select Track 1 Data
12. Send ;
13. Skip ahead one character
14. Send up to character*
15. -
16. Send =
17. Skip ahead one character
18. Send up to character *
19. <
20. Send Control M
21. Save rule

The following two barcodes are included for troubleshooting purposes and are to be used only under the direction of Wordstock Support:

22. Set all Defaults
23. Erase all Rules

7.



SEND ?

11.



**SELECT TRACK 1
DATA**

8.



SEND CONTROL M

12.



SEND ;

9.



SAVE RULE

13.



**SKIP AHEAD 1
CHARACTER**

10.



**ANY MAGSTRIPE
READER**

14.



**SEND UP TO
CHARACTER***

15.



-

19.



<

16.



SEND =

20.



SEND CONTROL M

17.



SKIP AHEAD 1
CHARACTER

21.



SAVE RULE

18.



SEND UP TO
CHARACTER*

See page 4 for two special barcodes that are reserved for troubleshooting purposes. Please do NOT use these barcodes unless directed to by Wordstock Support.

REMINDER: do NOT use these barcodes unless directed to by Wordstock Support.

22.



SET ALL DEFAULTS

23.



ERASE ALL RULES